



BABY WATCH

Security for Maternity units

Operation:

The BABY WATCH sensor mattress is placed in the cot and the battery operated alarm unit fitted to the outside using the existing 15mm ventilation hole.

The alarm is activated by the baby's mother or member of nursing staff turning the security key to the ON position when the baby is in place and removing it.

Once set, should the baby be lifted from the cot or the connections tampered with, the alarm will immediately sound. To disconnect the alarm, the key is re-inserted and turned to the OFF position.

A facility exists to link the Baby Watch to remote alarms/call system; this will involve a separate site visit and costing.



Technical Information:

CotAlarmUnit:	80 x 145 x 35mm
Weight:	300 g
Siren:	O/P two- tone etc
Power:	9V Alkaline PP3 battery
SensorMattress:	600 x 300 x 30mm
Weight:	1100 g
Sensitivity:	1.5 kg upwards 1.2 kg on low weight models
Waterproof:	Tested 1lb/sq inch submerged for 1 hour
Heat Tested:	175C for 3 hours
Material:	Polyurethane coated nylon
Hygiene:	Wipe with standard cot cleaning solutions
Fire Test:	Non burn/non smoke/non toxic
Fitting:	External mounting via existing 15 mm hole in cot

Model Options:

BBW-O1A - standard crib alarm (for babies over 1.5kg)

BBW-O1L - low weight alarm (for babies over 1.2kg)

Conformity:

BS 5455 (1977) - Mattress Covers
BS 4737 3.9 (1978) - Pressure Mats,
Alarm system warning devices.

1988 Schedule of Statutory Instrument
1324 Fire & Safety Regulations

The product carries a CE marking.

Note: The Baby Watch is classed as a
security device (not medical equipment)
and conforms to the relevant standards for
alarm systems.



BARTEC AUTO ID LIMITED
B.B.I.C, INNOVATION WAY
BARNSELY, S.YORKSHIRE
ENGLAND S75 1JL
T: +44(0)1226 770581
F: +44(0)1226 731647
E: enquires@bartecautoid.com